


Sensory Den

ERLSENT/ ERSENT

Dimensions: 100 x 100 x 100cm

Material: 210T polyester taffeta with silver coated flame retardant, 19mm PVC rod, PE floor.



The Sensory den blocks light from entering, providing children with a cosy, dark and safe place, free from distractions. Or a place to enjoy visual and sound stimulation, including UV light sources.

Inside the carry bag you will find:

1. 8 x Corner connectors
2. 12 x PVC rod
3. 1 x Flame retardant dark den



Carry bag included

Assembly is really simple just follow these 4 easy steps.

Step 1.

Lay your sensory dark tent out flat and thread 4 X PVC rods through the sleeves on the top of the dark tent. Connect a corner connector to each of the four corners.



Step 2.

Turn over the dark tent so that the black PE flooring is facing up. Repeat step 1 by threading the PVC rods through the sleeves on the bottom of the sensory dark tent and then apply the four corner connectors.

Step 3.

Connect the upright PVC rods and turn your sensory dark tent the correct way round with silver top and black PE flooring at the bottom.



Step 4.

Enjoy your sensory dark tent. Either experience the absence of light with the window and door flaps closed or simply roll and tie them to let light in. The sensory dark tent can provide the perfect place for a sensory experience using light emitting accessories.

This product requires adult assembly, it is not to be assembled by a child. Please keep out of reach of children until the tent is fully assembled. Made in China.