

1

3

B x 3

1

B

2

2 x 2

3

A x 4

1

A

3

3

C x 4

1

C

4

3

B x 3

1

3

B

5

2 x 2

3

A x 4

1

3

A

6

3

C x 4

1

3

C

7

G x 2

4 x 2

5 x 2

G

G

1

2 x 4

3 x 2

4 x 2

5 x 2

ME30979 20241111

Accessories Included:

A x 8

B x 12

C x 8

D x 8

E x 8

F x 16

G x 2

H x 1



I x 1

ME32539



Purchased Separately

Tool Required




8





9



10






11



ME32539
Purchased Separately

12




FINISHED

WARNING:
CHOKING HAZARD - Small Parts.
Not For Children Under 3 Years.

masterkatz



WARNING:
Adult assembly required. This item contains small parts that have sharp points and edges in the unassembled state. Adults must be extra careful to securely tighten all screws, make sure the toy is properly assembled, and ensure there are no left-over metal parts (eg. Allen key) within reach of children.



Movable Outdoor Rainbow Chimes