

Instructions for Inflatable Sensory Pod

PLLE29 - 48" Comfy Hugging Peapod Sensory Pod -Blue

PLLE30 - 60" Comfy Hugging Peapod Sensory Pod

PLLE32 - 80" Comfy Hugging Peapod Sensory Pod

WARNING! This product is not a toy. Do not use for anything else other than what it is intended for.

WARNING! RISK OF SUFFOCATION

- Infants have suffocated on inflatable mattresses. Never place an infant 15 months and younger to sleep on an inflatable mattress.
- When used by children over 15 months old:
 - Provide at least a shoulder width space between mattress and walls, dressers or other vertical objects to avoid entrapment.
 - Always keep mattress fully inflated when in use.

Benefits:

- ✓ Calming and Relaxing - Comfy Peapod's soothing deep pressure offers a comforting hug, facilitating a calming sense of security. Just a few minutes in the Comfy Peapod quiets and calms down most kids. Perfect for those who are fidgety and can't sit still.
- ✓ Increase Focus - The soft embrace when sitting relieves anxiety and stress resulting in greater concentration when reading, working, and socializing and a more attentive behavior.
- ✓ Soft, Durable and Easy to Use - The inflatable Comfy Peapod comes with an electric pump, so it is fast, easy and fun to blow up. Made with the finest flocked super-strong vinyl with heavy-duty triple-welded seams the Comfy Peapod is soft like velvet and strong for kid's play.
- ✓ Perfect Size For School or Home

48x26.5x17 inches – for kids ages 3-6 – for height up to 4 inch tall – Maximum weight 220lbs

60x30x17 inches – for kids ages 6-12 – for heights up to 5'1" – Maximum weight 350lbs

80x30x17 inches – Maximum weight 550lbs

- ✓ Sensory Comfort - Support kids with ADHD, autism and sensory processing disorder.

Inflation Instructions:

Follow these instructions for easy, quick setup of your Peapod. For best results, first lay Peapod flat on a clean surface, and connect your air pump to a power outlet.

1. Inflating the base

IMPORTANT: You must inflate the base first!

- Each stopper consists of 2 parts, the lower stopper and the upper stopper (fig A)
- Insert lower air stopper into valve opening until snug (fig B)
- Insert pump nozzle into stopper opening (fig C)
- Turn on pump and fill until firm (do not over-inflate)
- Turn off pump and insert final air stopper (fig D)

2. Inflating the sides

Once base is inflated, repeat steps above for each side. To deflate sides and base simply remove lower (and upper) air stopper

Care Instructions:

To clean wipe the surface with a damp cloth or sponge using soapy water and air-dry. Do not use strong chemicals or submerge in water.

A repair kit is provided with instructions.

Do not keep in extreme temperatures

Important Information and Recommendations

Designed for single child; the 203cm(80 inch) is suitable for 2-3 children or 1 adult/

Maximum weight 220lbs (48 inch size), 350lbs (60 inch size). 550lbs (80 inch size)

Not for children under 3 years old.

Use with adult supervision – **DO NOT USE IN WATER**

- Not a flotation device

Do not use a needle pump to inflate

Bouncyband prides itself on our high-quality products and customer service. We warranty each Comfy Peapod against any manufacturing defects. This Warranty is void if the product is punctured by a sharp object.

To prevent accidental puncturing, do not jump in or on the Peapods and keep away from all sharp objects (e.g. pencils, pens, scissors etc.)

Repair Instructions:

- 1) Deflate Comfy Peapod completely and lay on a clean, smooth hard surface. Use a soft damp rag or sponge to clean the area and remove any excess dirt or other particles.
- 2) Do **NOT** continue repair when surface is **moist!** Make sure the area is completely dry before continuing to proceed.
- 3) Flatten the deflated top and bottom of the Comfy Peapod so that the top and bottom are touching and smooth so there are no wrinkles. Clean the damaged area with rubbing alcohol and do the same for the patch.
- 4) Cut a smooth circular or oval patch with no sharp or irregular edges from the patch material provided. The patch should be 1 inch wider or more around the perimeter than the hole all around.
- 5) Lay the patch without glue on top of the hole with the shiny side facing down. The patch should be covering the hold with the edge of each section of the patch an equal distance from the edge of the hole. **DO NOT GLUE**
- 6) To best measure where the final placement of the patch will be, trace outside of the patch onto the surface of the Comfy Peapod. Use a light-colored crayon or colored pencil to create the circle on the peepod. The tracing line should be 1 inch bigger than the hole on each side so the tracing should be at least one inch away from the hole on all points.
- 7) Apply thin, even coat of glue from the patch kit to the shiny side of the patch. Apply and spread the glue onto the Peapod inside and just outside of the traced line. Be sure that the edges of the whole patch would later fit inside the glue area. **DO NOT APPLY THE PATCH**
- 8) Give the glue a short time (3-6 minutes) to set and become a little sticky
- 9) Carefully place the patch over the hole, exactly where you have traced out the line on the Peapod. Next use a smooth hard tool and rub intensely to secure properly to the peapod.
- 10) Place a flat heavy object (e.g. thick book) over the patch and leave it for 24-36 hours.
- 11) After 24 hours check to be sure that the patch is 100% secure. If so, it is time to re-inflate the Comfy peapod.

- * **VIDEO INSTRUCTIONS** are available at: bouncyband.com/pages/installation-guide