



Harness


Assembly Guide






IMPORTANT
WARNINGS
ON BACK














WARNING



DO NOT LEAVE CHILDREN UNATTENDED
EVEN WHEN HARNESS IS USED

Ensure harness lock is properly secured
Incorrect installation may result in
insability & weakness

Keep plastic bags away from children
ONLY for use by children who are able
to sit unaided

Do not use the harness unless all
components are correctly fitted &
adjusted. Check frequently

Do not use the harness if any parts are
broken, torn or missing

Please read warnings & notices on high
chairs related to this product

CONSUMER ASSISTANCE

HOTLINE: +61 (0) 2 9980 6633

SKYPE: tikktokk.mb

EMAIL: info@tikktokk.com

WEB: www.tikktokk.com

ADDRESS: Unit 3, 280 New Line Rd,
Dural, NSW, 2158,
Australia

EXPORTER

TikkTokk HONG KONG
Room 1-2-1304, Tome Mansion
No139 Fuzhou North Rd
266032 Qingdao
Shandong China

IMPORTER

TikkTokkAustralia
Unit 3, 280 New Line Rd
Dural, NSW, 2158
Australia