


Specification:	Contents:
Size: 178*178*150mm (approx) Weight: 1.22kg (approx)	1 x Light Source
Material: Aluminium alloy +LED	1 x Connector
45 Non-replaceable LEDs	1 x Remote Control
Input: 220 – 240V 50/60Hz Output: 24V 2A	1 x Adaptor
(Fibre optic tails are purchased separately)	












WARNING!
Contains sequences of flashing lights which may affect individuals who are susceptible to photosensitive epilepsy or other photosensitivities.

- Safety Warnings:**
- Before setting up your light, ensure the product is not damaged. If any part of the product is damaged, do not attempt to assemble and use.
 - Only use the adaptor and light source unit supplied with this product and no other adaptor or light source unit must be used.
 - Do not shine the light source directly in anyone's eyes.
 - This is not a toy, keep out of reach of children and pets, as it contains small parts which may cause a choking hazard.
 - This light source is for indoor use only and should not be used outdoors.
 - Avoid use in damp or moist conditions.
 - Do not allow any part to come into contact with excessive heat or naked flames.
 - Carry out regular checks to ensure fixings, fittings and installation has not become loose.
 - If the unit becomes damage do not attempt to dismantle or repair this product. Please contact the manufacturer for advice.

- Instructions**
1. Loosen the Lock Screw on front of the light source.
 2. Attach the connector and tighten the screw.
 3. Insert the end of the fibre optic tails into the hole in the front of the connector and tighten by turning the black ring on the connector tube.
- 
4. Firstly, connect the pin end of the adaptor to the back of the light source. Plug the adaptor to the mains sockets. Switch on from the mains.
 5. Test the remote control to ensure all functions are working.
 6. This item can be installed in various ways, from ceilings, through walls, along floors. Before installing, please ensure to complete a risk assessment for the product, it's home and the persons the item is intended to be used by.

The Fibre optic tails are purchased separately, we have 1.5m x 150 tails, 2m x 200 tails and 3m x 200 length tails available. Please contact Playlearn Ltd for further details.

Remote Control Functions

	Turn ON/OFF the light		Press this Key to save the DIY colour you adjust be the DIY brightness adjust key		Fades through 3 colours
	Increase/Decrease brightness when in static mode. Press to increase/decrease speed when in dynamic mode		DIY jump cycle mode		Fades through 7 colours
	Static colour modes		Jumps through 3 colours		Sparkling affect
	Press the DIY key to address the Green, Red, Blue colour brightness to choose the specific colour		Jumps through 7 colours		

- To change battery on the remote control please follow the instructions on the reverse side of the remote. The remote control requires CR2025 Lithium battery to operate. Please pull out the tab before use.

Battery Warnings! Batteries should only be inserted or changed by an adult. Non-rechargeable batteries are not to be recharged. Be sure to insert batteries with the correct polarities and always follow the product and battery manufacturers' instructions. Remove batteries from product before extended storage. Always remove old or exhausted batteries from the product. The supply terminals are not to be short circuited. Check that the contact surfaces are clean and bright before installing batteries. Do not mix different types of batteries. Do not bury or burn batteries. Recycle used batteries responsibly. Do not mix old and new batteries. Do not dispose of in household waste.

Warning: Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



Disposal: The "Crossed Wheelie Bin" symbol on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.