




Installation Instructions for Middle and High School Chairs

17" to 24" School Chair


1. Stretch each Bouncyband loop around the groove at the top of both tubes.




2. Turn the chair on it's side.

- a.) Place the front chair leg that is on the floor inside one of the tubes.
- b.) Step on the chair leg that is resting on the floor and pull the band up to stretch onto the remaining front leg.
- c.) Slide the top tube on the remaining front leg.

* The Bouncyband is 17" and it will stretch up to 24", so don't worry about breaking it.



3. Turn the chair back upright. When installed, the tension from the band keeps the Bouncyband and tubes in place when the chair is lifted or stacked.



***VIDEO INSTRUCTIONS are available at:
bouncyband.com/pages/installation-guide**

NOTE: Bouncybands are also available for elementary school chairs and individual desks.

Latex free